


FRONT

80 mm

— Crop
- - - - - Fold



Cover

DEVICE OVERVIEW

- Touch Sensor Temples**
 - Swipe forward: decrease volume & reject calls
 - Swipe backward: increase volume & receive calls
- Frame Front Corner Tap**
 - Single Tap: Music Play/Pause
 - Double Tap: Voice Assistant
- Home Button**
 - Short Press: Accept Call/Hang up, Next Song
 - Short Double Press: Previous Song
 - Long Press: Pairing, Power On/OFF, Reject Call
- Temple Lock Button**
 - Press to remove temple

P.1

POWERING ON/OFF

- TO POWER ON** your Revo Sonic. Hold down the Home Button until the Power Status prompt is heard, and the LED light is flashing blue. Revo Sonic will automatically connect to last paired device.
- TO POWER OFF** your Revo Sonic. Hold down the Home Button until "Power Off" prompt is heard, and the LED light turns off.
- Revo Sonic will automatically power off if placed upside down for 3 minutes.

P.2

BLUETOOTH PAIRING

- Make sure your Revo Sonic is off. Press and hold down the Home Button for 5 seconds until the LED light starts flashing red/blue and "Pairing" prompt is heard.
- Turn on Bluetooth connectivity on your device and put your Revo Sonic next to it.
- Open Bluetooth settings on your device and connect to "Revo Sonic".
- Revo Sonic's LED light will flash blue once it is paired.

P.3

MUSIC

- TO PAUSE / PLAY MUSIC** Single tap on the upper front corner of the frame.
- TO PLAY NEXT** Single press the Home Button.
- TO PLAY PREVIOUS** Double click the Home Button.

P.4

PHONE CALLS

- TO ACCEPT** a phone call. Single press the Home Button, OR Swipe your finger backward along the right temple.
- TO REJECT** a phone call. Long press the Home Button, OR Swipe your finger forward along the right temple.
- TO END** a phone call. Single press the Home Button.

P.5

CALL WAITING

- TO ACCEPT** a second incoming call. Single press the Home Button. Your current call will be ended.
- TO REJECT** a second incoming call. Long press the Home Button.

P.6

BACK

@Revo

@RevoSunglasses

@RevoSunglasses

revo | BLACK

Back Cover

VOLUME CONTROL

- TO INCREASE VOLUME** Swipe your finger backward along the right temple.
- TO DECREASE VOLUME** Swipe your finger forward along the right temple.

NOTE: Each swipe backward or forward will adjust the volume by one level, and a sound to confirm is heard.

P.7

VOICE ASSISTANT

- TO ENABLE** Voice Assistant. Double tap on the upper front corner of the frame. Once you hear the voice assistant tone, you can start the voice command.
- TO DISABLE** Voice Assistant. Double tap on the upper front corner of the frame.

P.8

CHARGING

- Connect the magnetic charging cable to the Revo Sonic charging points located on the inside of the temple.
- Plug the USB connector of the charging cable into the USB port of a charger or computer.
- The LED light will turn red while charging, and turn blue once it is fully charged. Revo Sonic will automatically turn off while charging.
- When you disconnect the charging cable from your sunglasses, Revo Sonic will turn on and automatically reconnect to the last paired device.

P.9

MOBILE APP

The Revo Sonic mobile app is an optional feature and available for both iOS and Android.

P.10

LED LIGHTING MODE

No signal	Revo Sonic is off or out of battery
Blue color flashing every 2 seconds	Waiting for Bluetooth to connect
Blue color flashing every 1 second	Bluetooth connected
Red/Blue color flashing	Pairing
Red/Blue color flashing fast	Incoming phone call
Red color	Charging
Blue color	Fully Charged

P.11

CARE INSTRUCTIONS

To keep your sunglasses clean, use your Revo pouch or a soft cloth. To remove smudges, use Revo Lens Wipes or a Revo Lens Cleaning Set, specifically developed for mirror coated sun lenses.

Please check our website for FAQs. revo.com/pages/faq

For warranty information, please visit Revo.com.

P.12

Approved by: _____
Date: _____